


## **ASSEMBLY INSTRUCTION FOR soni PORTA**

1.



Before applying the sound insulation elements, please make sure that the side of the door to be covered is free of dust, grease and other release agents.

For an easy and smooth installation process, we recommend laying out the **soni PORTA** elements in the correct order on the floor or table before actual mounting.

2.



As a first step, measure the door's height.

For a standard-height door (1,985 mm), use the 10-mm installation aid to ensure the same distance between the individual sound-insulation panels.

For a door with a lower height, we recommend using the 8-mm installation aid.

3.




Start with the bottom panel. Remove the protective film from the back and place the panel flush with the bottom edge of the door (see drawing). Make sure that the panel is positioned exactly in the center before pressing it firmly into place. Now place the installation aid on the upper edge of the already fitted panel and then position the next panel (after removing the protective film) above it, taking care to center it. Press firmly to fix the panel to the door surface. Repeat this step for the other insulation panels.

4.



soni porta outside of door



soni PORTA inside of door

For an optimum acoustic effect, all insulation elements must be pressed firmly into place. The final adhesive strength (100%) is reached after 24 hours.

Please note: Our **soni PORTA** door insulation panels can be removed again easily. To do this, simply lift one corner of the heavy layer and then peel off the entire panel. However, it is then no longer possible to reattach the panel.

VERSION 09/21